



PO Box 709 • Willow, AK 99688  
907-892-8600 • akclearwatermechanical@gmail.com

If your power goes out please take the following steps to help insure your on-demand doesn't freeze.

- 1) Unplug unit
- 2) Close hot and cold valves on bottom of unit by pulling valve handle toward you.



- 3) Open drains and let water flow out of unit into bucket. Leave drains open until you are ready to reverse process to turn unit back on.



To get the unit back up and running reverse process above. Before plugging in unit and turning it back on you MUST turn on a faucet or fixture to hot and let water run while starting unit to fill heat exchanger so it doesn't burn up.

\*AKCM IS NOT RESPONSIBLE FOR ANY DAMAGE TO WATER HEATER THAT IS NOT RELATED TO OUR WORKAMNSHIP.